

**PARAMERS SETUP FOR YOUR GLIDER/MOTORGLIDER IN ORDER TO ALLOW FLIGHTS AUTOMATIC RECORDING AT SISTERON**

<b>FLARM EQUIPMENT</b>	NORMAL	TESTED SUCCESSFULLY	<b>OUR PREFERRED SETUP</b>
	STEALTH MODE	TESTED - NOT WORKING -	
	NO-TRACKING	TESTED - NOT WORKING -	

<b>OGN</b>	REGISTRATION NUMBER			<b>ANONYMOUS</b>
	YOUR REAL REGISTRATION NUMBER	TESTED SUCCESSFULLY	<b>OUR PREFERRED SETUP</b>	NO
	A DUMMY REGISTRATION NUMBER: eg : X-ABCD	TESTED SUCCESSFULLY	WE RECOMMAND STARTING WITH "X-"	YES
	LEAVE THE FIELD BLANK	TESTED SUCCESSFULLY	VALUE MUST BE " " (read "blank caracter")	YES
	FLARM ID	<b>MUST BE THE GOOD ONE (1)</b>		NO CHOICE
	I DON'T WANT TO BE IDENTIFIED	NO (2)	OUR PREFERRED SETUP - TESTED SUCCESSFULLY	NO CHOICE
	I DON'T WANT TO BE TRACKED	NO (2)	OUR PREFERRED SETUP - TESTED SUCCESSFULLY	NO CHOICE
	I DON'T WANT TO BE IDENTIFIED	YES (3)	TESTED - NOT WORKING -	
	I DON'T WANT TO BE TRACKED	YES (3)	TESTED - NOT WORKING -	

<b>REQUEST FOR A FLIGHT PERIOD</b>	REGISTRATION	YOUR REAL REGISTRATION NUMBER	NO CHOICE
	FLARM ID	<b>MUST BE THE GOOD ONE (1)</b>	NO CHOICE
	OGN ID	<b>THE DUMMY REGISTRATION DECLARED IN THE OGN</b>	MANDATOTY IF YOU HAVEMADE THIS CHOICE

**NOTES**

- (1) - MUST COME FROM THE LOG FILE - OTHERS SOLUTION NOT 100% SURE
- (2) - BOX MUST REMAIN UNTICKED for NO
- (3) - PLACE A TICK IN THE BOX FOR YES



**AERoclub INTERNATIONAL SISTERON**  
 Aérodrome, 04200 Vaumeilh  
 +33 (0)4 92 62 17 45  
 www.volavoile-sisteron.com  
 aeroclubsisteron@gmail.com

EXAMPLE

OGN DDB ( [ddb.glidernet.org](http://ddb.glidernet.org) )

MY DEVICES

**ADD DEVICE**

CHANGE PASSWORD

DISCONNECT

## Register a device

Device type: Flarm

Device ID: DD9E8B

Aircraft type: Janus C

Registration: F-CFAP

Competition Number: AP

I don't want this device to be identified

I don't want this device to be tracked

### Full participation

- Tracking applications that use the OGN DDB will mark the position with aircraft identification
- Aircraft registration and CN are published in the OGN Devices Database

I certify to be the owner of this device

SUBMIT CANCEL